Dashboard


- Lifting plan tile

Lifting plan tile


How to manage lifting plans with the Smart Jobsite Application

Add the lifting plan tile

When you start the Smart Jobsite application, afterthe login you have acces to the dashboard




To add the lifting plan tile you can click on the + button. Then click on the tile button under the + Button



The ifting plan tile will be instantiated





Tile menu

You can click on the  button to acces to the tile menu




Scan a QR code

From the tile menu you can click on the  button to launch the QR code



Once the qr code is scanned you will have acces to the following window




Thanksto this window you can see the detail of the scanned part like :

- the rigging infotmations


- the part informations

To start the lifting you can click on the  button at the top right of the window.


You will go back to this window and the processing task will blink



Add a new lift

To add a new lift you can click on the  button. A new task will be created you can then edit it if you want


refresh the tile

You can use the  button to refresh the tile if needed

Change jobsite or crane

The lifting plan tile is associated to a jobsite and a crane. You can access to the settings to change it.


If you click on the setting button  to access to the following page [



] (https://bookstack.smartjobsite.com/uploads/images/gallery/2021-01/image-1611262417014.jpg)

You can use the two dropdowns to change the Jobsite and / or the crane

Delete the tile

You can use the button  to delete the tile