


# Lifting plan tile


## How to manage lifting plans with the Smart Jobsite Application

### Add the lifting plan tile


When you start the Smart Jobsite application, after the login you have access to the dashboard



To add the lifting plan tile you can click on the + button. Then click on the tile button under the + Button




The ifting plan tile will be instantiated




## Tile menu


You can click on the  button to access the tile menu






Scan a QR code



From the tile menu you can click on the button to launch the QR code




21:46












SMART  
JOBSITE

PLAN  
MANAGE  
REPORT



WO 01295

Elingage

Typical Products: Beams and Walls (including Twineall, Sandwich Panels and Solid Wall)						Lift Type
Recommended Equipment						1A
2 Leg Chains	3 Leg Chains	4 Leg Chains	Equaliser	Beam	Air-hoist	Number of Lifting Points
						2
1	0	0	0	0	0	Pitch unit from horizontal to vertical allowed?
<div><div><p>60 degree angle minimum from horizontal</p></div><div></div></div> <div>Notes: Tilt table may first be required.</div>						<input type="checkbox"/> No
						2 Point Lift – No Pitching
						


1A

200 Kg

2 Lifting Points

riggig type 1a

Elements



1781A-WH05FA-206

Walls

0.00t

- the rigging informations


- the part informations




To start the lifting you can click on the button at the top right of the window.

You will go back to this window and the processing task will blink






Add a new lift



To add a new lift you can click on the button. A new task will be created you can then edit it if you want


## refresh the tile




You can use the button to refresh the tile if needed

## Change jobsite or crane

The lifting plan tile is associated to a jobsite and a crane. You can access to the settings to change it.




If you click on the setting button to access to the following page [



] (<https://bookstack.smartjobsite.com/uploads/images/gallery/2021-01/image-1611262417014.jpg>)

You can use the two dropdowns to change the Jobsite and / or the crane

## Delete the tile



You can use the button to delete the tile

---

Revision #1

Created 21 January 2021 19:32:04 by Kevin

Updated 26 January 2021 07:47:00 by Kevin