User Data Base


- User database

User database


How to manage the user database

> The user database contains all the user informations like load charts, rigging type, ...


Under the Smart Jobsite tab you can click on the User DB button




You will have acces to the following panel



Under crane you can create/edit/delete load charts and crane engines properties.



Under rigging you can create/edit/delete rigging types


Rigging
New Rigging
Name
New Rigging
Weight (kg)
0.00
Number Of Lifting Points
1
Description
Drop files here (JPG, PNG)
Select File